LIFETIME

INSTRUCTION MANUAL

TRIPLE THREAT™
ROD HOLDER



SAVE THIS INSTRUCTION IN THE EVENT THE MANUFACTURER NEEDS TO BE CONTACTED.

TOOLS REQUIRED

NO TOOLS REQUIRED

TABLE OF CONTENTS

Rod holder assembly.....2
Securing a fishing rod.....2
Maintenence.....3

QUESTIONS?

Dial **1-800-225-3865**

CONTACT LIFETIME® CUSTOMER SERVICE:

Live Chat: **www.lifetime.com/customerservice**
(click on "LIVE CHAT" tab)

For Customer Service in Mainland Europe and the United Kingdom,
E-mail: csinternational@lifetime.com

PRODUCT ID:

1 ROD HOLDER ASSEMBLY

- Locate the small plastic tab on the rod holder, and the notch in the plastic mounting base. Align the tab with the notch and insert the rod holder into the mounting base as shown.



- *Your kayak may be different than the model shown, but the steps performed still apply.*



- *Please note, the Triple Threat™ Rod Holder will mount to a raised or flat mounting base.*

- Rotate the rod holder to lock it in place.



2 SECURING A FISHING ROD

- To secure a fishing rod to the rod holder:
  1) Place your fishing rod into the rod holder.
  2) Lock the rod in place by turning the plastic latch over the top of the rod.



- *The Triple Threat™ Rod Holder will accomodate most spinning, baitcasting, and fly fishing rods.*



Spinning Rod



Baitcasting Rod



Fly Rod

Video Tutorial:
go.lifetime.com/rodholder

MAINTENANCE

Congratulations on your Lifetime® Products purchase. By following the instructions below, your new Triple Threat™ Rod Holder should provide you with years of service and enjoyment.

Cleaning and Care

The Lifetime® Triple Threat™ Rod Holder is stain- and solvent-resistant. Most stains can be removed, using a mild soap and a soft-bristled brush. Abrasive cleaning materials may scratch the plastic and are not recommended.

- Always store your rod holder out of direct sunlight when not in use.
- Clean with mild soap and water periodically to keep your product looking new.
- The Triple Threat™ Rod Holder is intended for use with spinning, baitcasting, and fly fishing rods.
- Use of the rod holder for anything other than its intended purpose may damage the product and will void any applicable warranty.

ENHANCE YOUR LIFETIME® WATERCRAFT BY ADDING ACCESSORIES OR OTHER GREAT PRODUCTS

To purchase accessories or other Lifetime products, visit us at:

www.lifetime.com

Or dial 1-800-424-3865

www.lifetime.com