LIFETIME

ASSEMBLY INSTRUCTIONS

SLAM-IT PRO® RIM

MODEL 5000



BEFORE ASSEMBLY:

- 2+ people recommended for setup.

COPY

Save this instruction in the event that the manufacturer has to be contacted for replacement parts.

TOOLS REQUIRED

9/16" (14 mm)

(x2)

1/2" (13 mm)

(x1)



(x1)

TABLE OF CONTENTS

Icon Legend.....2
Notices.....2
Assembly.....3
Registration.....6
Warranty.....7

QUESTIONS?

CONTACT LIFETIME CUSTOMER SERVICE:

Call: **1-800-225-3865**
7:00 am–5:00 pm (Monday–Friday) MST
and 9:00 am–1:00 pm Saturday MST

Live Chat:
www.lifetime.com/customerservice

Video Instructions:
www.youtube.com/lifetimeproducts

For Customer Service in Mainland Europe and the United Kingdom,
E-mail: cs@lifetimeproducts.eu

Model:
5000
Product ID:

ICON LEGEND

• Indicates special heed should be taken when reading.

• Indicates the parts to be used for a section.

• Indicates no parts required for a specific section.

• Indicates the hardware to be used for a section.

• Indicates no hardware required for a specific page.

• Indicates the tools to be used for a section.

• Indicates to use/not to use an electric drill for a specific step.


• Indicates the use of a centerlock nut. A nut with this marking will require some effort to tighten. This hardware was designed with this feature in order to prevent loosening later.

COPY

WARNINGS & NOTICES

SAFETY INSTRUCTIONS

FAILURE TO FOLLOW THESE WARNINGS MAY RESULT IN SERIOUS INJURY OR PROPERTY DAMAGE AND WILL VOID WARRANTY.

Owner must ensure that all players know and follow these rules for safe operation of the system.

To ensure safety, do not attempt to assemble this product without following the instructions carefully. Check entire box and inside all packing material for parts and/or additional instruction material. Before beginning assembly, read the instructions and identify parts using the hardware identifier and parts list in this document. Proper and complete assembly, use and supervision are essential for proper operation and to reduce the risk of accident or injury. A high probability of serious injury exists if this product is not installed, maintained, and operated properly.

- Two capable adults are recommended for this operation.

Most injuries are caused by misuse and/or not following instructions. Use caution when using this product.

1 ASSEMBLY

HARDWARE REQUIRED

Hardware Bag



AAR (x2)



AAQ (x2)



ABK (x4)



AAV (x2)



ADR (x4)



ABQ (x1)



APY (x1)



AOU (x1)

AOW (x1)

AJW (x2)

PARTS REQUIRED

Metal Parts



ALX (x1)



AMA (x1)

Plastic Parts



AKZ (x1)



ALD (x1)

TOOLS REQUIRED

9/16" (14 mm)

(x2)

1/2" (13 mm)

(x1)

(x1)

▶ SECTION 1 (CONTINUED)

TOOLS AND HARDWARE REQUIRED











1.1

- Insert the **Carriage Bolts (AAR)** through the **Pivot Bracket (APY)** as shown.



1.2

- Use the 1/2” socket head from the socket head wrench to press one **Push Nut (AAQ)** onto one end of the **Axle (ABQ)**.



- *The Push Nut should rest about 1/4" from the end of the Axle. If the Push Nut slips on too far, continue sliding it to the other end of the Axle to remove it and try again.*

1.3

- Slide the end of the **Axle (ABQ)** through the **Rim (ALX)** and the **Rim Pivot Bracket (APY)**. Press the **Push Nut (AAQ)** onto the end of the Axle. Use the 1/2” socket head to secure the Push Nut if needed.







- *The Push Nut should rest about 1/4" from the end of the Axle. If the Push Nut slips on too far, continue sliding it to the other end of the Axle to remove it and try again.*

▶ SECTION 1 (CONTINUED)

TOOLS AND HARDWARE REQUIRED

9/16" (14 mm)



AOU (x1)

ABK (x2)

1.4

- Insert the **U-Bolt (AOU)** through the upper holes on the backside of the Backboard (not included). Secure the Rim and **Plastic Guard (ALD)** to the Backboard with the **Flange Nuts (ABK)** provided.

Rim Support Channel (not included)

- ***THIS STEP MAY NEED TO BE PERFORMED DIFFERENTLY!***
  When attaching the Rim to a Backboard, you will first need to attach the U-Bolt to the proper mounting equipment. See the assembly instructions included with your Basketball System or Mounting Kit before completing this step.



▶ SECTION 1 (CONTINUED)

TOOLS AND HARDWARE REQUIRED



AAV (x2)



ABK (x2)

AOW (x1)

AJW (x2)



ADR (x4)

1.5

- Thread the **Jam Nuts (AAV)** onto the U-Bolt as far as they will go, then secure the **Springs (AJW)** and **Spring Retainer Plate (AOW)** to the U-Bolt.





1.6

- Attach the **Rim Cover Plate (AMA)** to the Rim using the four **3/8-inch Screws (ADR)** provided.



1.8

- Attach the **Net (AKZ)** to the Rim.



- *If a replacement Net is needed, please call our Customer Service Department. Our Nets are shorter than average to reduce the risk of entanglement.*

REGISTER YOUR PRODUCT ONLINE AT WWW.LIFETIME.COM

At Lifetime®, we are committed to providing innovative and quality products. While registering, you will have the opportunity to give us your feedback. Your input is valuable to us.

- You can also opt in to receive new product notifications or promotions.
- In the unlikely event of a product recall or safety modification, your registration provides the information we need to notify you directly.
- Registration is fast, easy, and completely voluntary.

LIFETIME'S PROMISE TO YOU:

Maintaining your privacy is our long-standing policy at Lifetime®. And you can rest assured that Lifetime® will not sell or provide your personal data to other third parties, or allow them to use your personal data for their own purposes.

We invite you to read our privacy policy at www.lifetime.com

REGISTER today!

5-YEAR LIMITED FACTORY WARRANTY

THE MANUFACTURER RESERVES THE RIGHT TO MAKE SUBSTITUTIONS TO WARRANTY CLAIMS IF PARTS ARE UNAVAILABLE OR OBSOLETE.

1. Lifetime basketball systems are warranted to the original purchaser to be free from defects in material or workmanship for a period of five years from the date of original retail purchase. The word “defects” is defined as imperfections that impair the use of the product. Defects resulting from misuse, abuse or negligence will void this warranty. This warranty does not cover defects due to improper installation, alteration or accident. This warranty does not cover damage caused by vandalism, rusting, “acts of nature” or any other event beyond the control of the manufacturer.

2. This warranty is nontransferable and is expressly limited to the repair or replacement of defective product. If the product is defective within the terms of this warranty, Lifetime Products, Inc. will repair or replace defective parts at no cost to the purchaser. Shipping charges to and from the factory or distribution center are not covered and are the responsibility of the purchaser. Labor charges and related expenses for removal, installation or replacement of the basketball system or its components are not covered under this warranty.

3. This warranty does not cover scratching or scuffing of the product that may result from normal usage. In addition, defects resulting from intentional damage, negligence, unreasonable use or hanging from the rim will void this warranty.

4. Liability for incidental or consequential damages is excluded to the extent permitted by law. While every attempt is made to embody the highest degree of safety in all equipment, freedom from injury cannot be guaranteed. The user assumes all risk of injury resulting from the use of this product. All merchandise is sold on this condition, and no representative of the company may waive or change this policy.

5. This product is not intended for institutional or commercial use; Lifetime Products, Inc. does not assume any liability for such use. Institutional or commercial use will void the warranty.

6. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

7. This warranty is expressly in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for use to extent permitted by Federal and state law. Neither Lifetime Products, Inc., nor any representative assumes any other liability in connection with this product. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

PLEASE INCLUDE YOUR DATED SALES RECEIPT AND PHOTOGRAPHS OF DAMAGED PARTS.

REPORT PRODUCT DEFECTS IN WRITING TO:
Lifetime Products, Inc., PO Box 160010 Clearfield, UT 84016-0010
or call 1-800-225-3865 M-F 7 a.m. to 5 p.m. MST.

REGISTER YOUR PRODUCT FOR QUICKER CUSTOMER SERVICE.

Visit www.lifetime.com or call 1-800-225-3865 to register your product today.

FOR INTERNATIONAL WARRANTY CLAIMS:

All warranty claims must be accompanied by a sales receipt. Report all warranty claims in writing to your regional sales support representative. Please include your dated sales receipt and photographs of damaged parts.
To Identify the representative for your region, please visit: www.lifetime.com/international

LIFETIME®

www.lifetime.com

ENHANCE YOUR LIFETIME® PURCHASE BY ADDING ACCESSORIES OR OTHER GREAT PRODUCTS

To purchase accessories or other Lifetime® products, visit us at:

www.lifetime.com

Or call: 1-800-424-3865

7:00 am–5:00 pm (M–F) MST and 9:00 am–1:00 pm Saturday MST

www.lifetime.com